

ESW 7030

Handleless Gourmet warming drawer, 32 cm high for 90 cm high niche for preheating crockery, keeping food warm and low temperature cooking.




- The ultimate in enjoyment – low temperature cooking
- Always at the right temperature – four operating modes
- Convenient and easy – Touch control
- Push2open – opening the drawer couldn't be easier
- Better safe than sorry – timer with automatic switch-off

EAN: 4002516238744 / article number: 30703020F / material number: 11293670


Model and design	
Gourmet warming drawer	•
PureLine	•
VitroLine	•
ArtLine	•
Handleless	•
Colour	Obsidian black
Convenience features	
Pre-heating crockery	•
Keeping food warm	•
Perfect cooking results at low temperature	•
Operating modes	
Cup warming	•
Plate warming	•
Keeping food warm	•
Low temperature cooking	•
User convenience	
Capacity	12 place settings
Push2open mechanism	•
Fully telescopic runners for easy loading and unloading	•
Control panel with sensor controls	•
Control panel with symbols	•
Stop programming/Timer function	•
Sabbath programme	•
Cleaning convenience	
Flush control panel	•
Appliance networking	
MobileControl	•
Safety	
Cool front	•
Anti-slip mat	•
Safety switch-off	•
Technical data	
Appliance width in mm	595
Appliance height in mm	317
Appliance depth in mm	570
Useable interior height in mm	230
Total rated load in kW	0,7
Voltage in V	230
Frequency in Hz	50-60
Fuse rating in A	16
Number of phases	1
Mains cable with plug	•
Length of supply lead in m	2,0
Standard accessories	
Anti-slip mat	1
Rack for increased capacity	1

ESW 7030

Handleless Gourmet warming drawer, 32 cm high for 90 cm high niche for preheating crockery, keeping food warm and low temperature cooking.



ESW7030, installation drawings



ESW7030, installation drawings

A) 22 mm glass, 23,3 mm stainless steel